

## INSTALLATION INSTRUCTIONS

### DELTA<sup>®</sup>-LFS

#### Rough Opening Flashing & Sealant

##### Health and Safety

- Required safety equipment: hard hat, safety boots, gloves, safety glasses.
- Always follow all safety precautions as directed by the Occupational Safety and Health Administration (OSHA-USA) or the Construction Safety Association (Canada).
- Please refer to Safety Data Sheets for all components and observe all recommended safety precautions therein.
- The general codes of practice for protection at work and instructions of the manufacturers for tools and components are to be observed at all times.

##### Recommended Materials

- DELTA<sup>®</sup>-LFS

##### Recommended Tools

- Trowel
- Caulking gun
- Joint knife (for tooling)

##### Notes and Limitations

- These installation instructions for DELTA<sup>®</sup>-LFS are intended only as a guide and are for the convenience of the contractor, specifier, and other interested parties. The final application and details are the sole responsibility of the design authority on record for the project.
- All surfaces should be clean, dry, and free of dust, dirt, frost, damage, grease, excess mortar and sharp protrusions, standing water, and all other adhesion-limiting substances.
- Always confirm the local building code requirements prior to installation.
- An approved water-resistive barrier must be installed as per local building code requirements prior to the installation of DELTA<sup>®</sup>-LFS

##### Installation

- Apply DELTA<sup>®</sup>-LFS to substrate using appropriate caulking gun (see Detail 1).
- Install DELTA<sup>®</sup>-LFS membrane at sill. Overlap 2" (50 mm) onto vertical face of membrane and minimum 4" (100 mm) up the window jamb. (see Detail 2).
- Spread using a trowel to achieve a uniform membrane thickness of approximately 15 to 18 mils over the rough window opening. (see Detail 3).
- Apply a bead of DELTA<sup>®</sup>-LFS in each corner of the rough opening and then strike smooth with joint knife tool. (see Detail 4).
- Allow treated surfaces to skin over (approximately 30 minutes) before installing windows or doors and other wall assembly components.
- **Inspection**
- Inspect the DELTA<sup>®</sup>-LFS for any deficiencies in the continuity.

Dörken Systems Inc.  
4655 Delta Way  
Beamsville, Ontario  
L3J 0T6  
1-(905) 563-3255  
Fax: (905) 563-5582  
info@dorken.com  
www.dorken.com

The information printed in this brochure reflects product information and specifications at the date of printing. The manufacturer reserves the right to make changes when necessary. All rights reserved.

DELTA<sup>®</sup>-branded quality products  
manufactured by Dörken.

A DÖRKENGROUP company

